

## Sortiment renovovaných tonerových kaziet do tlačiarní, faxov a kopírovacích zariadení

platí od 12. augusta 2019

Typ kazety	Typ zariadenia
Brother TN-1030	Brother HL-1110E/1112E/DCP-1510E/1512E/MFC-1810E
Brother TN-2000	Brother HL-2030/2032/2040/2070N
Brother DR-2000	Brother HL-2030/2032/2040/2070N
Brother TN-2005	Brother HL-2035
Brother TN-2010	Brother HL-2130/DCP-7055/7055W/7057
Brother TN-2120	Brother HL-2140/2150N/2170W
Brother DR-2100	Brother HL-2140/2150N/2170W
Brother TN-2220	Brother HL-2240/2240D/2250DN/DCP-7060D/7065DN/7070DW/MFC-7360N/7460DN
Brother DR-2200	Brother HL-2130/2240/2240D/2250DN/DCP-7055/7060D/7065DN/7070DW/MFC-7360N/7460DN
Brother TN-2320	Brother HL-L23x0/DCP-L25x0/MFC-L27x0 series
Brother DR-2300	Brother HL-L23x0/DCP-L25x0/MFC-L27x0 series
Brother TN-2421	Brother HL-L23x2/DCP-L25x2/MFC-L27x2 series
Brother TN-3280	Brother HL-5340D/5350DN/5350DNL/5380DN/DCP-8070D/8085DN/MFC-8880DN
Brother TN-3380	Brother HL-5440D/5450DN/5470DW/6180DW/DCP-8110DN/8250DN/MFC-8510DN/8520DN/8950DW
Brother TN-230 K	Brother HL-3040CN/3070CW/MFC-9120CN/9320CW Black
Brother TN-230 C (M,Y)	Brother HL-3040CN/3070CW/MFC-9120CN/9320CW Cyan, Magenta Yellow
Brother TN-241 K	Brother HL-3140CW/3150CDW/3170CDW/DCP-9020CDW/MFC-9140CDN Black
Brother TN-245 C (M,Y)	Brother HL-3140CW/3150CDW/3170CDW/DCP-9020CDW/MFC-9140CDN Cyan, Magenta, Yellow
Brother TN-325 K	Brother HL-4150CDN/4570CDW/MFC-9460CDN/DCP-9270CDN/9055CDN Black
Brother TN-325 C (M,Y)	Brother HL-4150CDN/4570CDW/MFC-9460CDN/DCP-9270CDN/9055CDN Cyan, Magenta Yellow
Canon Cartridge 041	Canon LBP 312x/MF 522x/525x
Canon Cartridge 041H	Canon LBP 312x/MF 522x/525x
Canon Cartridge 045 Bk	Canon LBP 610C/MF 630C series Black
Canon Cartridge 045H Bk	Canon LBP 610C/MF 630C series Black
Canon Cartridge 045 C,M,Y	Canon LBP 610C/MF 630C series Cyan, Magenta, Yellow
Canon Cartridge 045H C,M,Y	Canon LBP 610C/MF 630C series Cyan, Magenta, Yellow
Canon Cartridge 046 Bk	Canon LBP 650C/MF 730C series Black
Canon Cartridge 046H Bk	Canon LBP 650C/MF 730C series Black
Canon Cartridge 046 C,M,Y	Canon LBP 650C/MF 730C series Cyan, Magenta, Yellow
Canon Cartridge 046H C,M,Y	Canon LBP 650C/MF 730C series Cyan, Magenta, Yellow
Canon Cartridge 047	Canon LBP 112/113w/MF 112/113w
Canon Cartridge 051H	Canon LBP 162dw/MF 264dw/267dw/269dw
Canon Cartridge 052	Canon LBP 212dw/214dw/215x/MF 421dw/426dw/428x/429x
Canon Cartridge 052H	Canon LBP 212dw/214dw/215x/MF 421dw/426dw/428x/429x
Canon Cartridge 703	Canon LBP 2900/3000
Canon Cartridge 707 Bk	Canon LBP 5000 Black
Canon Cartridge 707 C,M,Y	Canon LBP 5000 Cyan, Magenta, Yellow
Canon Cartridge 708	Canon LBP 3300/3360
Canon Cartridge 708H	Canon LBP 3300/3360
Canon Cartridge 711 Bk	Canon LBP 5300/5360/MF 8450/9130/9170 Black
Canon Cartridge 711 C,M,Y	Canon LBP 5300/5360/MF 9130/9170 Cyan, Magenta, Yellow
Canon Cartridge 712	Canon LBP 3010/3100
Canon Cartridge 715	Canon LBP 3360/3370
Canon Cartridge 715H	Canon LBP 3360/3370
Canon Cartridge 716 Bk	Canon LBP 5050/5050N/MF 8030CN/8050CN Black
Canon Cartridge 716 C,M,Y	Canon LBP 5050/5050N/MF 8030CN/8050CN Cyan, Magenta, Yellow
Canon Cartridge 717 C,M,Y	Canon MF 8450 Cyan, Magenta, Yellow
Canon Cartridge 718 Bk	Canon LBP 7200CDN/MF 8330CDN/8350CDN Black
Canon Cartridge 718 C,M,Y	Canon LBP 7200CDN/MF 8330CDN/8350CDN Cyan, Magenta, Yellow
Canon Cartridge 719	Canon MF 5840DN/5880DN
Canon Cartridge 719H	Canon MF 5840DN/5880DN
Canon Cartridge 720	Canon MF 6680DN
Canon Cartridge 723 Bk	Canon LBP 7750CDN Black
Canon Cartridge 723H Bk	Canon LBP 7750CDN Black
Canon Cartridge 723 C,M,Y	Canon LBP 7750CDN Cyan, Magenta, Yellow
Canon Cartridge 724	Canon LBP 6750DN
Canon Cartridge 724H	Canon LBP 6750DN
Canon Cartridge 725	Canon LBP 6000 series
Canon Cartridge 726	Canon LBP 6200D
Canon Cartridge 728	Canon MF 4410/4430/4450/4550D/4570DN/4580DN
Canon Cartridge 729 Bk	Canon LBP 7010C/7018C Black
Canon Cartridge 729 C,M,Y	Canon LBP 7010C/7018C Cyan, Magenta, Yellow
Canon Cartridge 729 OPC	Canon LBP 7010C/7018C fotomodul

Canon Cartridge 731 Bk	Canon LBP 7100Cn/7110Cw/MF 8230Cn/8280Cw Black
Canon Cartridge 731H Bk	Canon LBP 7100Cn/7110Cw/MF 8230Cn/8280Cw Black
Canon Cartridge 731 C,M,Y	Canon LBP 7100Cn/7110Cw/MF 8230Cn/8280Cw Cyan, Magenta, Yellow
Canon Cartridge 732 Bk	Canon LBP 7780Cx
Canon Cartridge 732H Bk	Canon LBP 7780Cx
Canon Cartridge 732 C,M,Y	Canon LBP 7780Cx
Canon Cartridge 737	Canon MF 211/212w/216n/217w/226dn/229dw
Canon Cartridge T	Canon PCD 320/340/L380/400
Canon C-EXV40	Canon IR 1133, 1133A, 1133iF
Canon E-30	Canon FC 1xx/2xx/3xx/ PC 7xx/8xx
Canon EP 27	Canon LBP 3200/MF 3110/56x0/57x0
Canon FX-3	Canon L200/240/260i/280/290/300/350/360
Canon FX-10	Canon L100/120
DELL LP1720	Dell Laser Printer 1720/1720dn
DELL LP1720 OPC	Dell Laser Printer 1720/1720dn fotomodul
Epson EPL-6200	Epson EPL-6200
Epson EPL-6200 OPC	Epson EPL-6200 fotomodul
HP CF 279 A	HP LJ Pro M12a/w/MFP M26a/nw
HP CF 217 A	HP LJ Pro M102a/w/MFP M130a/nw/fn/fw
HP CB 435 A	HP LJ P1005/1006
HP CE 285 A	HP LJ P1102/1102w/M1132/1212nf
HP CB 436 A	HP LJ P1505/M1120mfp/M1522mfp
HP CE 278 A	HP LJ P1566/P1606dn
HP Q 2612 A	HP LJ 1010/1012/1015/1018/1020/1022/M1005/M1319/3015/3020/3030/3050/3052/3055 series
HP CE 310 A	HP LJ CP1012/nw/Pro 100 M175a/nw/M275 Black
HP CE 311 (2,3) A	HP LJ CP1012/nw/Pro 100 M175a/nw/M275 Cyan, Yellow, Magenta
HP CE 314 A	HP LJ CP1012/nw/Pro 100 M175a/nw/M275 fotomodul
HP C 4092 A	HP LJ 1100 series/3200 series
HP Q 2624 A	HP LJ 1150 series
HP CB 540 A	HP LJ CP1215/1515/1518/CM1312mfp Black
HP CB 541 (2,3) A	HP LJ CP1215/1515/1518/CM1312mfp Cyan, Yellow, Magenta
HP C 7115 A	HP LJ 1000w/1005w/1200 series/1220/3300/3380 series
HP C 7115 X	HP LJ 1200 series/1220/3300/3380 series
HP CF 283 A	HP LJ Pro M201n/201dw/MFP M125nw/127fn/127fw/225dn/225dw
HP CF 283 X	HP LJ Pro M201n/201dw/MFP M225dn/225dw
HP Q 2613 A	HP LJ 1300 series
HP Q 2613 X	HP LJ 1300 series
HP Q 5949 A	HP LJ 1160/1320/3390/3392 series
HP Q 5949 X	HP LJ 1320/3390/3392 series
HP CE 320 A	HP LJ CP1525n/nw/CM1415fn/fnw Black
HP CE 321 (2,3) A	HP LJ CP1525n/nw/CM1415fn/fnw Cyan, Yellow, Magenta
HP CF 350 A	HP LJ Pro MFP M176n/M177fw Black
HP CF 351 (2,3) A	HP LJ Pro MFP M176n/M177fw Cyan, Yellow, Magenta
HP CF 530 A	HP LJ Pro M180n/M181fw Black
HP CF 531 (2,3) A	HP LJ Pro M180n/M181fw Cyan, Yellow, Magenta
HP CF 230 A	HP LJ Pro M203dn/dw/MFP M227sdn/fdw
HP CF 230 X	HP LJ Pro M203dn/dw/MFP M227sdn/fdw
HP CF 210 A	HP LJ Pro 200 M251/M276 series Black
HP CF 210 X	HP LJ Pro 200 M251/M276 series Black
HP CF 211 (2,3) A	HP LJ Pro 200 M251/M276 series Cyan, Yellow, Magenta
HP Q 7553 A	HP LJ P2014/P2015/M2727 series
HP Q 7553 X	HP LJ P2015/M2727 series
HP CC 530 A	HP LJ CP2025/CM2320mfp series Black
HP CC 531 (2,3) A	HP LJ CP2025/CM2320mfp series Cyan, Yellow, Magenta
HP CE 505 A	HP LJ P2035/P2055 series
HP CE 505 X	HP LJ P2055 series
HP C 4096 A	HP LJ 2100 series/2200 series
HP Q 2610 A	HP LJ 2300 series
HP Q 6511 A	HP LJ 2410/20/30 series
HP Q 6511 X	HP LJ 2410/20/30 series
HP C 9700 A	HP LJ 2500/1500 series Black
HP C 9701 (2,3) A	HP LJ 2500/1500 series Cyan, Yellow, Magenta
HP C 9704 A	HP LJ 2500/1500 series fotomodul
HP Q 3960 A	HP LJ 2550/2820/2840 series Black
HP Q 3961 (2,3) A	HP LJ 2550/2820/2840 series Cyan, Yellow, Magenta
HP Q 3964 A	HP LJ 2550/2820/2840 series fotomodul
HP CF 400 A	HP LJ M252n/dw/Pro M274n/M277n/dw Black
HP CF 400 X	HP LJ M252n/dw/Pro M274n/M277n/dw Black
HP CF 401 (2,3) A	HP LJ M252n/dw/Pro M274n/M277n/dw Cyan, Yellow, Magenta
HP CF 401 (2,3) X	HP LJ M252n/dw/Pro M274n/M277n/dw Cyan, Yellow, Magenta
HP CF 540 A	HP LJ Pro M254dw/nw/M280nw/M281fdn/fdw Black

HP CF 540 X	HP LJ Pro M254dw/nw/M280nw/M281fdn/fdw Black
HP CF 541 (2,3) A	HP LJ Pro M254dw/nw/M280nw/M281fdn/fdw Cyan, Yellow, Magenta
HP CF 541 (2,3) X	HP LJ Pro M254dw/nw/M280nw/M281fdn/fdw Cyan, Yellow, Magenta
HP Q 6000 A	HP LJ 1600/2600/2605/CM1015/CM1017 series Black
HP Q 6001 (2,3) A	HP LJ 1600/2600/2605/CM1015/CM1017 series Cyan, Magenta, Yellow
HP Q 7560 A	HP LJ 2700/3000 series Black
HP Q 7561 (2,3) A	HP LJ 2700/3000 series Cyan, Magenta, Yellow
HP CE 410 A	HP LJ Pro 300 M351/Pro 400 M451/M475 series Black
HP CE 410 X	HP LJ Pro 300 M351/Pro 400 M451/M475 series Black
HP CE 411 (2,3) A	HP LJ Pro 300 M351/Pro 400 M451/M475 series Cyan, Yellow, Magenta
HP Q 7551 A	HP LJ P3005/M3035mfp/M3027mfp series
HP Q 7551 X	HP LJ P3005/M3035mfp/M3027mfp series
HP CE 255 A	HP LJ P3015 series
HP CE 255 X	HP LJ P3015 series
HP Q 2670 A	HP LJ 3500/3550/3700 series Black
HP Q 2671 (2,3) A	HP LJ 3500/3550 series Cyan, Yellow, Magenta
HP CE 250 A	HP LJ CP3525/CM3530 series Black
HP CE 250 X	HP LJ CP3525/CM3530 series Black
HP CE 251 (2,3) A	HP LJ CP3525/CM3530 series Cyan, Yellow, Magenta
HP Q 6470 A	HP LJ 3600/3800/CP3505 series Black
HP Q 6471 (2,3) A	HP LJ 3600 series Cyan, Yellow, Magenta
HP Q 2681 (2,3) A	HP LJ 3700 series Cyan, Yellow, Magenta
HP Q 7581 (2,3) A	HP LJ 3800/CP3505 series Cyan, Yellow, Magenta
HP 92298 A	HP LJ 4/4M/4+/4M+/5/5M/5N
HP 92298 X	HP LJ 4/4M/4+/4M+/5/5M/5N
HP CF 280 A	HP LJ Pro M401a/d/dn/dw/MFP M425dn/dw
HP CF 280 X	HP LJ Pro M401a/d/dn/dw/MFP M425dn/dw
HP CF 226 A	HP LJ Pro M402n/dn/dw/MFP M426dw/fdn/fdw
HP CF 226 X	HP LJ Pro M402n/dn/dw/MFP M426dw/fdn/fdw
HP CF 410 A	HP LJ Pro M452nw/dn/dw/MFP M477fnw/fdn/fdw Black
HP CF 410 X	HP LJ Pro M452nw/dn/dw/MFP M477fnw/fdn/fdw Black
HP CF 411 (2,3) A	HP LJ Pro M452nw/dn/dw/MFP M477fnw/fdn/fdw Cyan, Yellow, Magenta
HP CF 411 (2,3) X	HP LJ Pro M452nw/dn/dw/MFP M477fnw/fdn/fdw Cyan, Yellow, Magenta
HP CF 380 A	HP LJ Pro MFP M476nw/dw Black
HP CF 380 X	HP LJ Pro MFP M476nw/dw Black
HP CF 381 (2,3) A	HP LJ Pro MFP M476nw/dw Cyan, Yellow, Magenta
HP C 4127 X	HP LJ 4000/4050 series
HP CB 400 A	HP LJ CP4005 series Black
HP CB 401 (2,3) A	HP LJ CP4005 series Cyan, Yellow, Magenta
HP CC 364 A	HP LJ P4014/4015/4515
HP CC 364 X	HP LJ P4015/4515
HP C 8061 X	HP LJ 4100 series
HP Q 1338 A	HP LJ 4200 series
HP Q 1339 A	HP LJ 4300 series
HP Q 5942 A	HP LJ 4250/4350 series
HP Q 5942 X	HP LJ 4250/4350 series
HP Q 5945 A	HP LJ 4345mfp/M4345mfp
HP CE 260 A	HP LJ CP4020/4025/4520/4525/CM4540 series Black
HP CE 260 X	HP LJ CP4520/4525 series Black
HP CE 261 (2,3) A	HP LJ CP4020/4025/4520/4525 series Cyan, Yellow, Magenta
HP CE 264 X	HP LJ CM4540 serie Black
HP CF 031 (2,3) A	HP LJ CM4540 serie Cyan, Yellow, Magenta
HP C 9720 A	HP LJ 4600/4650 series Black
HP C 9721 (2,3) A	HP LJ 4600/4650 series Cyan, Yellow, Magenta
HP Q 5950 A	HP LJ 4700 series Black
HP Q 5951 (2,3) A	HP LJ 4700 series Cyan, Yellow, Magenta
HP Q 6460 A	HP LJ 4730mfp series Black
HP Q 6461 (2,3) A	HP LJ 4730mfp series Cyan, Yellow, Magenta
HP 92274 A	HP LJ 4L/4ML/4P/4MP
HP CF 287 A	HP LJ Ent M501n/dn/M506n/dn/x/MFP M527dn/f/c
HP CF 287 X	HP LJ Ent M501n/dn/M506n/dn/x/MFP M527dn/f/c
HP CE 400 A	HP LJ Ent 500 M551/Pro MFP 570/575 series Black
HP CE 400 X	HP LJ Ent 500 M551/Pro MFP 570/575 series Black
HP CE 401 (2,3) A	HP LJ Ent 500 M551/Pro MFP 570/575 series Cyan, Yellow, Magenta
HP CF 360 A	HP LJ Ent M552dn/553n/dn/x/M577dn//CM577f/c Black
HP CF 360 X	HP LJ Ent M552dn/553n/dn/x/M577dn//CM577f/c Black
HP CF 361 (2,3) A	HP LJ Ent M552dn/553n/dn/x/M577dn//CM577f/c Cyan, Yellow, Magenta
HP CF 361 (2,3) X	HP LJ Ent M552dn/553n/dn/x/M577dn//CM577f/c Cyan, Yellow, Magenta
HP C 4129 X	HP LJ 5000/5100 series
HP Q 7570 A	HP LJ M5025/5035 series
HP Q 7516 A	HP LJ 5200 series

HP CE 740 A	HP LJ CP5225 series Black
HP CE 741 (2,3) A	HP LJ CP5225 series Cyan, Yellow, Magenta
HP CE 270 A	HP LJ CP5525 series Black
HP CE 271 (2,3) A	HP LJ CP5525 series Cyan, Yellow, Magenta
HP C 3906 A	HP LJ 5L/6L/3100/3150
HP C 3903 A	HP LJ 5P/5MP/6P/6MP
HP CE 390 A	HP LJ Ent 600 M601/602/603/4555
HP CE 390 X	HP LJ Ent 600 M602/603/4555
HP CF 281 A	HP LJ Ent M604/605/606/630 series
HP CF 214 A	HP LJ Ent 700 M712 series
HP CF 214 X	HP LJ Ent 700 M712 series
HP CE 340 A	HP LJ Ent 700 M775 series Black
HP CE 341 (2,3) A	HP LJ Ent 700 M775 series Cyan, Yellow, Magenta
HP C 8543 X	HP LJ 9000/9040/9050/M9040/M9050 series IUT
IBM 1312	IBM InfoPrint 1312
Kyocera TK-17	Kyocera FS 1000/1000+/1010/1050
Kyocera TK-55	Kyocera FS 1920
Kyocera TK-120	Kyocera FS 1030D/1030DN
Kyocera TK-130	Kyocera FS 1028/1128/1300N/1300D/1350DN/
Kyocera TK-160	Kyocera FS 1120D/Ecosys P2035D
Kyocera TK-170	Kyocera FS 1320D/1370DN/Ecosys P2135D/DN
Kyocera TK-310	Kyocera FS 2000D/DN
Kyocera TK-340	Kyocera FS 2020D
Kyocera TK-350	Kyocera FS 3920DN/3040MFP/3040MFP+/3140MFP+/3140/3540/3640MFP
Kyocera TK-475	Kyocera FS 6025MFP/6030MFP/6525MFP/6530MFP
Kyocera TK-1170	Kyocera Ecosys M2040dn/2540dn/2640idw
Kyocera TK-3100	Kyocera FS 2100D/DN/4200DN/Ecosys M3040dn/M3540dn
Kyocera TK-3130	Kyocera FS 4200DN/4300DN
Kyocera TK-3160	Kyocera Ecosys P3045n/P3050dn/P3055dn/P3060dn
C540H1KG	Lexmark C540/543/544/X543/544 serie Black
C540H1CG (M,Y)	Lexmark C540/543/544/X543/544 series Cyan, Magenta, Yellow
C544X1KG	Lexmark C544/X544/546 series Black
C544X1CG (M,Y)	Lexmark C544/X544/546 series Cyan, Magenta, Yellow
70C2HK0 702HK	Lexmark CS310/410/510 series Black
70C2HC0 702HC (M,Y)	Lexmark CS310/410/510 series Cyan, Magenta, Yellow
80C20K0 802K	Lexmark CX310/410/510 series Black
80C20C0 802C (M,Y)	Lexmark CX310/410/510 series Cyan, Magenta, Yellow
80C2SK0 802SK	Lexmark CX310/410/510 series Black
80C2SC0 802SC (M,Y)	Lexmark CX310/410/510 series Cyan, Magenta, Yellow
80C2HK0 802HK	Lexmark CX410/510 series Black
80C2HC0 802HC (M,Y)	Lexmark CX410/510 series Cyan, Magenta, Yellow
80C2XK0 802XK	Lexmark CX510 series Black
80C2XC0 802XC (M,Y)	Lexmark CX510 series Cyan, Magenta, Yellow
12016SE	Lexmark Optra E 120/120N
12S0400	Lexmark Optra E 220
034016HE	Lexmark Optra E 230/232/240/330/332/340/342 series
12A8302	Lexmark Optra E 230/232/240/330/332/340/342 series fotomodul
E250A11E	Lexmark Optra E 250/350/352 series
E260A11E	Lexmark Optra E 260/360/460 series
E260X22G	Lexmark Optra E 260/360/460 series fotomodul
E352H11E	Lexmark Optra E 350/352 series
E250X22G	Lexmark Optra E 250/350/352/450 series fotomodul
E360H11E	Lexmark Optra E 360/460 series
E460X11E	Lexmark Optra E 460 series
50F2000 502	Lexmark MS310/410/510/610 series
50F2H00 502H	Lexmark MS310/410/510/610 series
50F2X00 502X	Lexmark MS410/510/610 series
50F2U00 502U	Lexmark MS510/610 series
51B2000	Lexmark MS/MX 317/417/517/617 series
51B2H00	Lexmark MS/MX 417/517/617 series
51B2X00	Lexmark MS/MX 517/617 series
52D2000 522	Lexmark MS810/811/812 series
52D2H00 522H	Lexmark MS810/811/812 series
52D2X00 522X	Lexmark MS811/812 series
53B2H00	Lexmark MS817/818 series
60F2000 602	Lexmark MX310/410/510/511/611 series
60F2H00 602H	Lexmark MX310/410/510/511/611 series
60F2X00 602X	Lexmark MX510/511/611 series
62D2000 622	Lexmark MX710/711/810/811/812 series
62D2H00 622H	Lexmark MX710/711/810/811/812 series
62D2X00 622X	Lexmark MX711/810/811/812 series

63B2H00	Lexmark MX717/718 series
12A7462	Lexmark Optra T-630/632/634/X-630/632/634 MFP series
64016HE	Lexmark Optra T-640 series
64416XE	Lexmark Optra T-644 series
T650H11E	Lexmark Optra T-650/652/654 series
T654X11E	Lexmark Optra T-654 series
X203A11G	Lexmark X203/204 MFP
18S0090	Lexmark X215 MFP
X264H11G	Lexmark X264/363/364 MFP
Minolta PP-1300X	Minolta PagePro 1300 / 1350 / 1380
Minolta PP-1300 OPC	Minolta PagePro 1300 / 1350 / 1380 / 1390W / Di 1610 fotomodul
Minolta PP-1400	Minolta PagePro 1400w
Minolta PP-1400 OPC	Minolta PagePro 1400w fotomodul
Minolta TNP36	Minolta Bizhub 3300P/3300/3301
OKI 44992402	OKI B401/MB441/451
OKI 44574702	OKI B411/431/MB461/471/491
OKI 44574802	OKI B431/MB461/471/491
OKI 44917602	OKI B431/MB491
OKI 45807102	OKI B412/B432/B512/MB472/MB492/MB562
OKI 45807106	OKI B412/B432/B512/MB472/MB492/MB562
OKI 45807111	OKI B432/B512/MB492/MB562
OKI 44973536 (K)	OKI C301/321/MC332/342
OKI 44973535 (C,M,Y)	OKI C301/321/MC332/342
OKI 44469803 (K)	OKI C310/330/331/510/511/530/531/MC351/352/361/362/561/562
OKI 44469706 (C,M,Y)	OKI C310/330/331/510/511/530/531/MC351/352/361/362/561/562
OKI 46508712 (K)	OKI C332/MC363
OKI 46508711 (C,M,Y)	OKI C332/MC363
OKI 44469804 (K)	OKI C510/530/MC561
OKI 44973508 (K)	OKI C511/531/MC562
OKI 44469724 (C,M,Y)	OKI C510/511/530/531/MC561/562
OKI 43459332 (K)	OKI C3300/3400/3450n/3600n
OKI 43459331 (C,M,Y)	OKI C3300/3400/3450n/3600n
OKI 43459324 (K)	OKI C3500/3520/3530MFP/MC350/360
OKI 43459371 (C,M,Y)	OKI C3500/3520/3530MFP/MC350/360
OKI 43324408 (K)	OKI C5600/5700
OKI 43381907 (C,M,Y)	OKI C5600/5700
OKI 43865708 (K)	OKI C5650/5750
OKI 43872307 (C,M,Y)	OKI C5650/5750
OKI 43324424 (K)	OKI C5800/5900/5550MFP
OKI 43324423 (C,M,Y)	OKI C5800/5900/5550MFP
OKI 43865724 (K)	OKI C5850/5950/MC560
OKI 43865723 (C,M,Y)	OKI C5850/5950/MC560
OKI 44315308 (K)	OKI C610
OKI 44315307 (C,M,Y)	OKI C610
OKI 44643004 (K)	OKI C801/821
OKI 44643003 (C,M,Y)	OKI C801/821
OKI 44059108 (K)	OKI C810/830
OKI 44059107 (C,M,Y)	OKI C810/830
OKI 44844508 (K)	OKI C831/841
OKI 44844507 (C,M,Y)	OKI C831/841
OKI 44059168 (K)	OKI MC851/861
OKI 44059256 (K)	OKI MC861
OKI 44059167 (C,M,Y)	OKI MC851/861
OKI 44059255 (C,M,Y)	OKI MC861
OKI 44059212 (K)	OKI MC860
OKI 44059211 (C,M,Y)	OKI MC860
Samsung CLT-K406S	Samsung CLP 360/365/CLX 3300/33005 Black
Samsung CLT-C406S (M,Y)	Samsung CLP 360/365/CLX 3300/33005 Cyan, Magenta, Yellow
Samsung CLT-K4072S	Samsung CLP 320/325/CLX 3185 Black
Samsung CLT-C4072S (M,Y)	Samsung CLP 320/325/CLX 3185 Cayn, Magenta, Yellow
Samsung CLT-K4092S	Samsung CLP 310/315/CLX 3170/3175 Black
Samsung CLT-C4092S (M,Y)	Samsung CLP 310/315/CLX 3170/3175 Cayn, Magenta, Yellow
Samsung ML-1210D3	Samsung ML 1010/1020/1210/1210D/1210 Z/1220M/1220MD/1220MR/1250/1250D/1250Z, ML-1430/1550
Samsung ML-1520D3	Samsung ML 1520/1520P
Samsung ML-1610D2	Samsung ML 1610
Samsung ML-1630A	Samsung ML 1630/SCX 4500
Samsung ML-1710D3	Samsung ML 1410/1500/1510/1710/1750/1755, ML 1740
Samsung ML-2010D3	Samsung ML 2010/2010P/2015/2510/2570/2571N
Samsung ML-D2850B	Samsung ML 2850/2851
Samsung ML-D3470B	Samsung ML 3470/3471
Samsung MLT-D101S	Samsung ML 2160/2162/2165/W/2168/SCX 3400/F/3405/F/W/FW/SF 760P

Samsung MLT-D103L	
Samsung MLT-D111S	Samsung Xpress M2020/2022/2070 series
Samsung MLT-D111L	Samsung Xpress M2020/2022/2070 series
Samsung MLT-D116L	Samsung Xpress SL-M2625/2675/2825/2875 series
Samsung MLT-D1042S	Samsung ML 1660/1665/1860/1865/1865W/SCX-3200/3205/3205W
Samsung MLT-D1052L	Samsung ML 1910/1915/2525/2525W/2580N/SCX 4600/4623F/4623GN
Samsung MLT-D1082S	Samsung ML 1640/2240
Samsung MLT-D1092S	Samsung SCX 4300
Samsung MLT-D203L	Samsung SL-M3320ND/M3370FD/M3820DW/M3820ND/M3870FD/M3870FW/M4020ND/M4070FR
Samsung MLT-D203E	Samsung SL-M3820DW/M3820ND/M3870FD/M3870FW/M4020ND/M4070FR
Samsung MLT-D203U	Samsung SL-M4020ND/M4070FR
Samsung MLT-D204L	Samsung SL-M3325ND/M3375FD/M3825DW/M3825ND/M3875FD/M3875FW/M4025ND/M4025NX/M4075FR
Samsung MLT-D204E	Samsung SL-M3825DW/M3825ND/M3875FD/M3875FW/M4025ND/M4025NX/M4075FR
Samsung MLT-D204U	Samsung SL-M4025ND/M4025NX/M4075FR
Samsung MLT-D205L	Samsung ML 3310/3710/SCX 4833/5637/5737
Samsung MLT-D205E	Samsung ML 3710/SCX 5637/5737
Samsung MLT-D2092L	Samsung ML 2855ND/SCX 4824FN/4828FN
Samsung SCX-4100D3	Samsung SCX 4100
Samsung SCX-4200D3	Samsung SCX 4200
Samsung SCX-4521D3	Samsung SCX 4521
Xerox 106R02773	Xerox Phaser 3020/WorkCentre 3025
Xerox 106R02778	Xerox Phaser 3052/3260/WorkCentre 3215/3225
Xerox 106R01379	Xerox Phaser 3100
Xerox 109R00748	Xerox Phaser 3116
Xerox 106R01159	Xerox Phaser 3117/3122/3124/3125
Xerox 109R00725	Xerox Phaser 3130/3121
Xerox 108R00908	Xerox Phaser 3140/3155/3160 2k
Xerox 108R00909	Xerox Phaser 3140/3155/3160 2,5k
Xerox 106R01374	Xerox Phaser 3250
Xerox 106R01412	Xerox Phaser 3300MFP
Xerox 106R02306	Xerox Phaser 3320
Xerox 106R03623	Xerox Phaser 3330/WorkCentre 3335/3345
Xerox 106R01415	Xerox Phaser 3435
Xerox 106R02732	Xerox Phaser 3610/WorkCentre 3615
Xerox 108R00796	Xerox Phaser 3635
Xerox 106R01634	Xerox Phaser 6000/6010/WorkCentre 6015 Black
Xerox 106R01631 (2,3)	Xerox Phaser 6000/6010/WorkCentre 6015 Cyan, Magenta, Yellow
Xerox 013R00625	Xerox WorkCentre 3119
Xerox 113R00730	Xerox Phaser 3200
Xerox 106R01487	Xerox WorkCentre 3210/3220
Xerox 106R02310	Xerox WorkCentre 3315/3325
Xerox 106R02312	Xerox WorkCentre 3325
Xerox 106R01531	Xerox WorkCentre 3550
Xerox 013R00606	Xerox WorkCentre PE 120/120i